


Blackout Instructions

4" Skyline Pocket Installation – Inside Mount





<i>Components Needed</i>	_____	<i>page 3</i>
<i>Tools Needed</i>	_____	<i>page 4</i>
<i>System Diagram</i>	_____	<i>page 5</i>
<i>Instructions</i>		
Step 1: Install Brackets & End Plates	_____	Page 6
Step 2: Mount Pocket	_____	Page 6
Step 3: Mount Back Side Channels	_____	Page 7
Step 4: Install Shade	_____	Page 7
Step 5: Install Front Side Channel	_____	Page 8
Step 6: Install Bottom Channel	_____	Page 9
Step 7: Install Bottom Closure	_____	Page 9
Step 8: Install Tension Device	_____	Page 10
Installed Shade	_____	Page 10

Blackout Instructions

4" Skyline Pocket Inside Mount Installation

Quantity	Description	Image
1	4" Roller shade assembled to tube with clutch and idler inserted.	
2	4" Skyline Fascia Brackets	
2	End Plates	
1	4" Pocket	
1	Bottom Closure	
2	Front & Back Side Channels	
1	Bottom Channel	


Blackout Instructions

4" Skyline Pocket Installation Instructions

Tools Needed

Screwdriver/Power Drill
1/16" Metal Drill Bit
Screws
Hammer/Mallet
Measuring Tape
Level
Ladder
Center Punch
Eye Protection
Gloves

System Diagram



1	4" Pocket
2	Bottom Closure
3	Tube
4	Fabric with internal Hembar
5	Clutch
6	Idler
7	4" Skyline Fascia Brackets
8	4" End Plates
9	Front Side Channel
10	Back Side Channel
11	Bottom Channel
12	Tension Device


Blackout Instructions

4" Skyline Pocket Installation Inside Mount

Step 1: Install Brackets & End Plates into Pocket (if the system did not come assembled to installation site. Can be done prior to shipping)

1a. Insert Bracket into pocket

1b. Attach end plate onto the pocket with appropriate screws



Step 2: Mount Pocket

2a. Mark and pre-drill mounting screw holes, then using appropriate screws, install pocket into top or side of window frame.



Step 3: Mount Back Side Channels (follow steps for right and left back side channels)

3a. Mark mounting screw hole locations with a center punch .

3b. Pre-drill holes in the side of the side channel

3c. Align the back channel flush with the back of the pocket and mount with the correct mounting screws



Step 4: Install Shade

4a. Insert Idler first by pushing in the spring loaded pin end into the hole in the center of the bracket.

4b. Insert Clutch side by engaging the hooks on the core of the clutch into the holes in the bracket.




Step 5: Install Front Side Channel


5a. Snap front side channel by engaging lip of the channel into the groove on the back side channel. Snap front side channel into place



Engage lip into groove




Snap into place




Step 6: Install Bottom Channel

- 6a. Place left side of bottom channel between the front and back side channels
- 6b. Slide the right side down in between the front and back side channels until the bottom closure is sitting on the window sill
- 6c. Mount bottom channel to window sill using correct mounting screws.



For easier installation, slide light blocking brush up and out of the way while installing the bottom channel.



Step 7: Install Bottom Closure *(outside mount shown, instruction is the same for inside mount)*

- 8a. Insert bottom closure into pocket on an angle (as shown).
- 8b. Once it is aligned in shade, allow front of bottom closure to drop in place



Idler Side



Clutch Side



Idler Side



Clutch Side

Step 8: Install Tension Device



Installed Shade



