


# Roller Shade Cassette Motorization



## Standard Parts

1. Fabric
2. Aluminum Tube with Tape
3. Large Quiet Motor
4. Power Cord
5. Universal End Plug
6. Disc Screws
7. Flat Metal End Cap
8. Round Profile
9. Triangle Profile
10. Round Bottom Bar
11. Cassette Profile
12. Cassette Mounting Brackets
13. Cassette End Cap
14. End Plate
15. Motor Mount Screws
16. Bracket Assembly Motor Side
17. Idler Support Screws
18. Glue Pad
19. End Plate Screw
20. Drive Wheel
21. Idler Support
22. Cassette Wrap Components

## Optional Parts

23. Remote Control
24. Wireless Wall Switch
25. Wireless Timer

# Roller Shade Cassette Motorization

<b>No.</b>	<b>PCN</b>	<b>Description</b>			
1.	RLWTxxx	Woven Textures® Fabric	18.	RC450059	Glue Pad for End Caps
2.	RC445083	Aluminum Tube (16') – 2" OD with Tape	19.	RC450002	End Plate Screws
3.	RC445285	Large Quiet ST50 Motor	20.	RC445067	Drive Wheel
4.	Power Cords		21.	RC450075	Idler Support
	RC445071	3' Cord	22.	Cassette Wrap Components	
	RC445072	6' Cord		RC450058	Double Faced Tape
	RC445073	12' Cord		RC444959	Glue
5.	RC450076	Universal End Plug		444958	Poly Carbonate Strip (for cassette spline)
6.	WWC900155	Disc Screws	<b>Optional Parts:</b>		
7.	Flat Metal End Cap		23.	Wireless Remotes	
	RC415048	Black		RC445069	1 - Channel Remote
	RC415674	Bamboo Stalk		RC445079	4 - Channel Remote
	RC415903	Desert Gold	24.	Wireless Wall Switch	
	RC415859	Desert Tan		RC445135	1 - Channel Wall Switch
	RC415675	Polar White		RC445136	4 - Channel Wall Switch
	RC415307	Nickel	25.	RC445129	24 - Hour Wireless Timer
	RC415499	Antique Gold	*	RC445341	Sewn In Hem Bar
	RC415528	Bronze Shimmer™	<b>Installation Instructions/Labels/Hang Tags</b>		
8.	RC445086	Round Profile	*	LIT888245B	Roller Shades Quiet Motorized Standard and Cassette Installation Instructions
9.	RC445087	Triangle Profile	*	LIT888245BF	Roller Shades Quiet Motorized Standard and Cassette Installation Instructions French
10.	Round Bottom Bar		*	888105	Round Bar Warning Sticker (English/Spanish)
	RC418048	Black	*	7106858000	Round Bar Warning Sticker (English/French)
	RC418859	Desert Tan	*	LIT888094	"Do Not Remove" Wrap
	RC418903	Desert Gold	*	5117000248	Alustra® Carton Label
	RC418674	Bamboo Stalk			
	RC418675	Polar White			
	RC418307	Nickel			
	RC418492	Golden Brass			
	RC418528	Bronze Shimmer			
11.	RC466xxx	Large Cassette Profile (16')			
12.	Universal Mounting Brackets				
	RC412048	2 pack Large Cassette Bracket Black			
	RC412874	2 pack Large Cassette Bracket White			
	RC492048	3 pack Large Cassette Bracket Black			
	RC492874	3 pack Large Cassette Bracket White			
13.	RC456xxx	Large Cassette End Cap			
14.	End Plate				
	RMC601000L	Left Side End Plate			
	RMC601000R	Right Side End Plate			
15.	RC450071	Motor Mount Screws			
*	RC450069	6-32 Clinch Nut used with Motor-Mount Screws			
16.	RC450074	Bracket Assembly Motor Side			
17.	RC450070	Idler Support Screws			

xxx = 3-digit color code

\* These items are not shown