


Roller Shade Cassette



Standard Parts

1. Fabric
2. Tube with Tape
3. Clutch and Spring Pin
4. Bead Chain Loop
5. Universal Cord Tensioner
6. Bead Chain Stop
7. Flat Metal End Cap
8. Round Profile
9. Triangle Profile
10. Round Bottom Bar
11. Cassette Profile
12. Cassette Mounting Brackets
13. Cassette End Cap
14. End Plate
15. Glue Pad
16. UCT Mounting Kit
17. End Plate Screws
18. Cassette Wrap Components
19. Bead Chain Connector

Optional Parts

20. Hold Down Bracket

Roller Shade Cassette

No.	PCN	Description		
1.	RTWTxxx	Woven Textures® Fabric	RC418903	Desert Gold
2.	44492216	1½" Roller Tube with Tape	RC418674	Bamboo Stalk
3.	Clutch and Spring Pin		RC418675	Polar White
	RC431048	R16 1½" Clutch and Spring Pin Black	RC418307	Nickel
	RC431350	R16 1½" Clutch and Spring Pin Vanilla	RC418492	Golden Brass
4.	Bead Chain Spools		RC418528	Bronze Shimmer
	RC458048	Ball Chain (6mm Pitch) Black	11. RC466xxx	Large Cassette Profile (16')
	RC458674	Ball Chain (6mm Pitch) Bamboo Stalk	12. Cassette Mounting Brackets	
	RC458675	Ball Chain (6mm Pitch) Polar White	RC412048	2 pack Large Cassette Bracket Black
	RC458785	Ball Chain (6mm Pitch) Aspen White	RC412874	2 pack Large Cassette Bracket White
	RC458903	Ball Chain (6mm Pitch) Desert Gold	RC492048	3 pack Large Cassette Bracket Black
	RC133499	Ball Chain (6mm Pitch) Antique Gold	RC492874	3 pack Large Cassette Bracket White
	444904	Ball Chain (6mm Pitch) Nickel (Stainless Steel)	13. RC456xxx	Large Cassette End Cap
5.	Universal Cord Tensioner		14. End Plates	
	RC122048	Black	RC445133	Large Cassette Clutch End Plate Left
	RC122528	Bronze Shimmer™	RC445132	Large Cassette Clutch End Plate Right
	RC123785	Aspen White	RC450080L	Large Cassette Pin End Plate Left
	RC122674	Bamboo Stalk	RC450080R	Large Cassette Pin End Plate Right
	RC122859	Desert Tan	15. RC450059	Glue Pad for End Caps
	RC122903	Desert Gold	16. UCT Mounting Kit	
	RC122661	White Tiara	4150228002	Outside Mounting Kit
	RC122730	Antique Gold	4150228001	Flush Mounting Kit
	RC122731	Nickel	17. RC450002	End Plate Screws
6.	Bead Chain Stop		18. Cassette Wrap Components	
	RC130000	Bead Stop (Hollow Ball) Clear	RC450058	Double Faced Tape
	444906	Metal Bead Stop Nickel (Stainless Steel)	RC444959	Glue
	RC134499	Metal Bead Stop Antique Gold	444958	Poly Carbonate Strip (For Cassette Spline)
7.	Flat Metal End Cap		19. Bead Chain Connector	
	RC415048	Black	RC469000	Clear
	RC415674	Bamboo Stalk	444940	Nickel (Stainless Steel)
	RC415903	Desert Gold	RC135499	Antique Gold
	RC415859	Desert Tan	Optional Parts:	
	RC415675	Polar White	20. PC555270	Hold Down Bracket
	RC415307	Nickel	* RC445341	Sewn In Hem Bar
	RC415499	Antique Gold		
	RC415528	Bronze Shimmer		
8.	RC445086	Round Profile		
9.	RC445087	Triangle Profile		
10.	Round Bottom Bar			
	RC418048	Black		
	RC418859	Desert Tan		

Roller Shade Cassette

Installation Instructions/Labels/Hang Tags

- * LIT888305B Alustra® Standard Roller and Cassette Shade Installation Instructions
- * LIT888305BF Alustra Standard Roller and Cassette Shade Installation Instructions French
- * 888105 Round Bar Warning Sticker (English/Spanish)
- * 7106858000 Round Bar Warning Sticker (English/French)
- * LIT888094 "Do Not Remove" Wrap
- * 7107685000 Tension Safety Device Hang Tag
- * 5117000248 Alustra Carton Label

* These items are not shown.

xxx = 3 Digit Color Code.