


Cordless Lifting System with Cassette



Standard Parts

- | | | |
|--------------------------------|--|--|
| 1. Universal Mounting Brackets | 9. Cassette End Plate Attachments | 15. Profiles
a. = Small Or Large Round
b. = Triangle |
| 2. Clutch and Pin | 10. Cassette End Plate Attachment Screw (White Head) | 16. Round Bottom Bar |
| 3. Spring | 11. End Plate Screws | 17. Plastic Bottom Bar End Caps |
| 4. Speed Controller | 12. Cassette End Caps Glue Pads | 18. Decorative Pull |
| 5. Stop Controller | 13. Cassette Wrap Components | 19. Plastic Hold-Down Brackets (Optional) |
| 6. Cordless Tube | 14. Cassette End Caps | |
| 7. Large Cassette Profile 16' | | |
| 8. Cassette End Plates | | |

Cordless Lifting System with Cassette

No.	PCN	Description	No.	PCN	Description
1.	Large Cassette Brackets, 2 Pack RC412048 RC412977 RC412874	Black Gray White	14.	RC456xxx	Large Cassette End Cap
	Large Cassette Brackets, 3 Pack RC492048 RC492977 RC492874	Black Gray White	15.	Profiles RC445085 RC445086	Small Round Profile (For Thicker Fabrics) Large Round Profile (For Thinner Fabrics)
2.	Clutch and Pin RC450078 RC450079	Cordless Clutch Pin (to secure Clutch and Spring together)		RC445087	Triangle Profile
3.	Spring RC450100 RC450101 RC445322 RC450102 RC450103 RC450104	Set A Set B Set C Set D Set F Set Y	16.	RC418xxx	Round Bottom Bar
4.	Speed Controller RC450095 RC450096	800 GFCM Speed Controller 400 GFCM Speed Controller	17.	RC414xxx	Plastic Bottom Bar End Caps
5.	RC450097	Stop Controller	18.	Decorative Pull RC417xxx RC413xxx	Round Beveled
6.	RC450037	Cordless Tube	19.	PC555270	Plastic Hold-Down Brackets (Optional)
7.	RC466xxx	Large Cassette Profile 16'	Additional Components		
8.	Cassette End Plates (Roman/Motorized/Cordless) RMC601000L RMC601000R	Left Side Right Side		RC450120	Winder
9.	Cassette End Plate Attachments RC450116 RC450117	Stop Controller Side Holder Bracket (For Right Side End Plate) Spring Side Holder Bracket (For Left Side End Plate)	Shade Options (Upgrades)		
10.	RC450081	MT01 Cassette End Plate Attachment Screw (White Head)		RC416xxx RC415xxx RC445323	Beveled Flat Double Faced Adhesive For Faux Wood Slat And Designer Tape Trims
11.	RC450003	End Plate Screws		RC420xxx LIT888248	Faux Wood Slats Faux Wood Slat Label
12.	RC450059	Cassette End Caps Glue Pads	Upgrades for Designer Roller Shades		
13.	Cassette Wrap Components RC450058 PC444959 444958 RC445269 RC445280	Double Faced Tape Glue Polycarbonate Strip (For Thinner Fabrics) Small Polycarbonate Strip (For Thicker Fabrics) ¼" Tape For RC445269 Only		RC403xxx RC404xxx RC407xxx RC406xxx 445040	Grosgrain Tape Trim Grosgrain Stripe Tape Trim Herringbone Tape Trim Petite Gimp Trim Glue for Petite Gimp Trim
			Upgrade for Designer Screen Shades		
				RC445340	Sealed Hem Bar
			Installation Instructions / Labels / Hang Tags		
				LIT888315 LIT888315F LIT888094 888105 7106858000	Cordless (Std. and Cassette) Roller IOC (English Installation Instructions) Cordless (Std. and Cassette) Roller IOC (French Installation Instructions) "Do Not Remove" wrap (used as outer wrap on finished shades) Bottom Bar Warning Sticker (English/Spanish) Bottom Bar Warning Sticker (English/French)

xxx = Color Code